

Benzaldehyde, oxime, (E)-

Other names:	(E)-Benzaldehyde oxime (E)-Benzaldoxime syn-Benzaldoxime syn-Benzaldehyde oxime Benzaldehyde oxime, trans
Inchi:	InChI=1S/C7H7NO/c9-8-6-7-4-2-1-3-5-7/h1-6,9H
InchiKey:	VTWKXBJHBYJBI-UHFFFAOYSA-N
Formula:	C7H7NO
SMILES:	ON=Cc1ccccc1
Mol. weight [g/mol]:	121.14
CAS:	622-31-1

Physical Properties

Property code	Value	Unit	Source
hf	-21.29	kJ/mol	Joback Method
hvap	53.44	kJ/mol	Joback Method
log10ws	-0.78		Crippen Method
logp	1.495		Crippen Method
mvol	97.280	ml/mol	McGowan Method
pc	4046.64	kPa	Joback Method
tb	555.10	K	Joback Method
tc	773.37	K	Joback Method
tf	308.00	K	NIST Webbook

Pressure Dependent Properties

Property code	Value	Unit	Pressure [kPa]	Source
tbrp	377.20	K	0.80	NIST Webbook
tbrp	391.50 ± 0.50	K	1.30	NIST Webbook

Sources

Crippen Method:	https://www.chemeo.com/doc/models/crippen_log10ws
Joback Method:	https://en.wikipedia.org/wiki/Joback_method
McGowan Method:	http://link.springer.com/article/10.1007/BF02311772
NIST Webbook:	http://webbook.nist.gov/cgi/cbook.cgi?ID=C622311&Units=SI
Crippen Method:	http://pubs.acs.org/doi/abs/10.1021/ci990307l

Legend

hf:	Enthalpy of formation at standard conditions
hvap:	Enthalpy of vaporization at standard conditions
log10ws:	Log10 of Water solubility in mol/l
logp:	Octanol/Water partition coefficient
mcvol:	McGowan's characteristic volume
pc:	Critical Pressure
tb:	Normal Boiling Point Temperature
tbrp:	Boiling point at reduced pressure
tc:	Critical Temperature
tf:	Normal melting (fusion) point

Latest version available from:

<https://www.chemeo.com/cid/70-011-1/Benzaldehyde-oxime-E.pdf>

Generated by Cheméo on 2024-04-20 08:42:27.66193456 +0000 UTC m=+15891796.582511873.

Cheméo (<https://www.chemeo.com>) is the biggest free database of chemical and physical data for the process industry.