

Sources

Joback Method:	https://en.wikipedia.org/wiki/Joback_method
McGowan Method:	http://link.springer.com/article/10.1007/BF02311772
NIST Webbook:	http://webbook.nist.gov/cgi/cbook.cgi?ID=U352600&Units=SI
Crippen Method:	http://pubs.acs.org/doi/abs/10.1021/ci990307I
Crippen Method:	https://www.chemeo.com/doc/models/crippen_log10ws

Legend

cpg:	Ideal gas heat capacity
gf:	Standard Gibbs free energy of formation
hf:	Enthalpy of formation at standard conditions
hfus:	Enthalpy of fusion at standard conditions
hvac:	Enthalpy of vaporization at standard conditions
log10ws:	Log10 of Water solubility in mol/l
logp:	Octanol/Water partition coefficient
mccol:	McGowan's characteristic volume
pc:	Critical Pressure
rinpol:	Non-polar retention indices
tb:	Normal Boiling Point Temperature
tc:	Critical Temperature
tf:	Normal melting (fusion) point
vc:	Critical Volume

Latest version available from:

<https://www.chemeo.com/cid/73-924-5/Spermidine-N-N-N-tris-heptafluorobutyryl.pdf>

Generated by Cheméo on 2024-04-30 15:08:43.240261968 +0000 UTC m=+16778972.160839289.

Cheméo (<https://www.chemeo.com>) is the biggest free database of chemical and physical data for the process industry.