



## Sources

**Joback Method:** [https://en.wikipedia.org/wiki/Joback\\_method](https://en.wikipedia.org/wiki/Joback_method)

**NIST Webbook:** <http://webbook.nist.gov/cgi/inchi/InChI=1S/C12H26O6/c1-13-3-5-15-7-9-17-11-12-18-10-8-16-6-4-14-2/h3-12H2,1-2H3>

**Crippen Method:** <http://pubs.acs.org/doi/abs/10.1021/ci9903071>

## Legend

$C_{p,gas}$ : Ideal gas heat capacity (J/molxK).

$\eta$ : Dynamic viscosity (Paxs).

$\Delta_f G^\circ$ : Standard Gibbs free energy of formation (kJ/mol).

$\Delta_f H^\circ_{gas}$ : Enthalpy of formation at standard conditions (kJ/mol).

$\Delta_{fus} H^\circ$ : Enthalpy of fusion at standard conditions (kJ/mol).

$\Delta_{vap} H^\circ$ : Enthalpy of vaporization at standard conditions (kJ/mol).

$logP_{oct/wat}$ : Octanol/Water partition coefficient .

$P_c$ : Critical Pressure (kPa).

$T_{boil}$ : Normal Boiling Point Temperature (K).

$T_c$ : Critical Temperature (K).

$T_{fus}$ : Normal melting (fusion) point (K).

$V_c$ : Critical Volume (m<sup>3</sup>/kg-mol).

Latest version available from:

<https://www.chemeo.com/cid/85-259-1/2%2C5%2C8%2C11%2C14%2C17-Hexaoxaoctadecane>

Generated by Cheméo on Wed, 14 Nov 2018 11:29:38 +0000.

**Cheméo** (<https://www.chemeo.com>) is the biggest free database of chemical and physical data for the process industry.