

1-Propene, 1,1'-oxybis-, (E,Z)-

Other names:	Dipropenyl ether, (E,Z)-
Inchi:	InChI=1S/C6H10O/c1-3-5-7-6-4-2/h3-6H,1-2H3/b5-3-,6-4+
InchiKey:	ZKJNETINGMOHJG-CIIODKQPSA-N
Formula:	C6H10O
SMILES:	CC=COC=CC
Mol. weight [g/mol]:	98.14
CAS:	4696-29-1

Physical Properties

Property code	Value	Unit	Source
gf	55.08	kJ/mol	Joback Method
hf	-64.95	kJ/mol	Joback Method
hfus	12.89	kJ/mol	Joback Method
hvap	31.28	kJ/mol	Joback Method
log10ws	-2.12		Crippen Method
logp	2.070		Crippen Method
mcvol	92.670	ml/mol	McGowan Method
pc	3431.89	kPa	Joback Method
tb	367.42	K	Joback Method
tc	550.12	K	Joback Method
tf	169.45	K	Joback Method
vc	0.349	m ³ /kmol	Joback Method

Temperature Dependent Properties

Property code	Value	Unit	Temperature [K]	Source
cpg	153.37	J/molxK	367.42	Joback Method
cpg	163.10	J/molxK	397.87	Joback Method
cpg	172.40	J/molxK	428.32	Joback Method
cpg	181.26	J/molxK	458.77	Joback Method
cpg	189.72	J/molxK	489.22	Joback Method
cpg	197.78	J/molxK	519.67	Joback Method
cpg	205.46	J/molxK	550.12	Joback Method
dvisc	0.0030234	Paxs	169.45	Joback Method

dvisc	0.0012125	Paxs	202.44	Joback Method
dvisc	0.0006282	Paxs	235.44	Joback Method
dvisc	0.0003826	Paxs	268.44	Joback Method
dvisc	0.0002597	Paxs	301.43	Joback Method
dvisc	0.0001903	Paxs	334.43	Joback Method
dvisc	0.0001474	Paxs	367.42	Joback Method

Sources

Joback Method:	https://en.wikipedia.org/wiki/Joback_method
McGowan Method:	http://link.springer.com/article/10.1007/BF02311772
NIST Webbook:	http://webbook.nist.gov/cgi/cbook.cgi?ID=C4696291&Units=SI
Crippen Method:	http://pubs.acs.org/doi/abs/10.1021/ci990307l
Crippen Method:	https://www.chemeo.com/doc/models/crippen_log10ws

Legend

cp_g:	Ideal gas heat capacity
dvisc:	Dynamic viscosity
g_f:	Standard Gibbs free energy of formation
h_f:	Enthalpy of formation at standard conditions
h_{fus}:	Enthalpy of fusion at standard conditions
h_{vap}:	Enthalpy of vaporization at standard conditions
log₁₀ws:	Log ₁₀ of Water solubility in mol/l
log_p:	Octanol/Water partition coefficient
mcvol:	McGowan's characteristic volume
pc:	Critical Pressure
tb:	Normal Boiling Point Temperature
tc:	Critical Temperature
tf:	Normal melting (fusion) point
vc:	Critical Volume

Latest version available from:

<https://www.chemeo.com/cid/56-480-7/1-Propene-1-1-oxybis-E-Z.pdf>

Generated by Cheméo on 2024-04-23 10:40:49.019187791 +0000 UTC m=+16158097.939765102.

Cheméo (<https://www.chemeo.com>) is the biggest free database of chemical and physical data for the process industry.